



"They Get the Details Right"

Carpenters' Moulding Guide

AUSTIN

512 • 989 • 1445

GoWestPac.com



"They Get the Details Right"

For over 30 years, the local ownership of Western Pacific has been supplying the building industry with quality products for new home construction.

As an environmentally and socially conscious company, we source the majority of our windows, doors and mouldings from regionally owned and operated manufacturers in the Pacific Northwest.

Our mission is to supply quality products on time to meet evolving homebuilders' requirements. We appreciate your business and look forward to working together on your home.

ROUGH OPENINGS



LEFT HAND
SWING

INTERIOR SINGLE DOORS

DOOR SIZE	OPENING SIZE
2'-0"	26"X82"
2'-4"	30"X82"
2'-6"	32"X82"
2'-8"	34"X82"
3'-0"	38"X82"



RIGHT HAND
SWING

INTERIOR

ASTRAGAL PAIRS

DOOR SIZE	OPENING SIZE
2'-0"	50-1/2"X82"
2'-4"	58-1/2"X82"
2'-6"	62-1/2"X82"
2'-8"	66-1/2"X82"
3'-0"	74-1/2"X82"

BALL CATCH PAIRS

DOOR SIZE	OPENING SIZE
2'-0"	50"X82"
2'-4"	58"X82"
2'-6"	62"X82"
2'-8"	66"X82"
3'-0"	74"X82"

INTERIOR

BIFOLDS

DRYWALL JAMB:
(DOOR WIDTH + 1-1/4")

BIPASS DOOR

DRYWALL JAMB:
(DOOR WIDTH X 2)

WOOD FULL JAMB:
(DOOR WIDTH + 2")

WOOD FULL JAMB
(DOOR WIDTH X 2) + 1"

POCKET DOOR

WOOD FRAME
(DOOR WIDTH X 2) + 2"
(DOOR HEIGHT) + 4-1/2"
EXAMPLE: 2668 = 62" X 84"

JOHNSON FRAME
(DOOR WIDTH X 2) + 1"
(DOOR HEIGHT) + 4-1/2"
EXAMPLE: 2668 = 61" X 84-1/2"

EXTERIOR

EXTERIOR SINGLE DOORS

	6/8	7/0	8/0
2' 6"	32" X 83"	32" X 87"	32" X 99"
2' 8"	34" X 83"	34" X 87"	34" X 99"
2' 10"	36" X 83"	36" X 87"	36" X 99"
3' 0"	38" X 83"	38" X 87"	38" X 99"

12" TRANSOMS OVER 6'8" DOORS
ARE NORMALLY 94-1/2" HEIGHT

EXTERIOR SIDELITE UNIT

ONE SIDELITE, ONE DOOR
(DOOR WIDTH) + (S/L WIDTH) + 3-1/2"

TWO SIDELITES, ONE DOOR
(DOOR WIDTH) + (S/L WIDTH X 2) + 5"

TWO SIDELITES, TWO DOORS
(DOOR WIDTH X 2) + (S/L WIDTH X 2) + 6"

6' 8" HEIGHT: 83"

7' 0" HEIGHT: 87"

8' 0" HEIGHT: 99"

EXTERIOR PAIRS

(DOOR WIDTH X 2) + 3"

6' 8" HEIGHT: 83"

7' 0" HEIGHT: 87"

8' 0" HEIGHT: 99"

SERVICES



JOB SITE TAKEOFF

Our experienced, professional team will walk your jobsite and do a detailed takeoff, including as needed: prehung doors, millwork, stairparts, locks & hardware, and windows.



PREHUNG DOORS

Your dedicated WestPac team will machine and assemble our quality doors together with jambs, brickmould, weatherseals, and other components into a ready-to-install unit, with great care and quality in mind.



CUSTOM DOORS

If you're aiming for unique interior design, or exclusive entry doors, we have experts on hand who will transform your creative vision into reality.



CUSTOM MILLWORK

Whether it's beautiful arch surrounds and casing, custom run moulding patterns, or exotic wood species, we have you covered with WestPac's experienced custom millwork shop.



HAND PULLED MOULDING PACKS

We take pride in our vast assortment of casing, base, crown, and closet material, and we'll handle with care as we package your items in the quantities and lengths you need.



JOB SITE DELIVERY


We deliver, rain or shine, on time to your jobsite. We get your order right and deliver it to your site quickly, so you can meet your deadlines with no surprises.





MOBILE APP

Maximize your efficiency by getting up-to-the-minute updates on your order status and delivery schedule by using our WestPac mobile app.

BASIC MOULDING TERMINOLOGY




BASIC MOULDING TERMINOLOGY



TRADITIONAL

Style

A



MOULDING

FLAT STOCK


INTERIOR DOORS

STAIR PARTS

CRAFTSMAN

Style

B



TECHNICAL INFORMATION

NOTES

CRAFTSMAN

Style

C

MOULDING

WP309

1X2

RIPPED

FLAT STOCK

INTERIOR DOORS

18PSG

1X4

1X6

STAIR PARTS

1X4

CLASSIC

Style

D

TECHNICAL INFORMATION

NOTES

WP398

WPB695

1X2

WP705

1X6

1X4

WP703


WP112

WPB695

TRADITIONAL

Style

E



MOULDING

FLAT STOCK


INTERIOR DOORS

STAIR PARTS

TRADITIONAL

Style

F



TECHNICAL INFORMATION

NOTES

TRADITIONAL

Style

G

MOULDING


FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION


NOTES



CRAFTSMAN

Style

H



MOULDING

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES



WP216

S4S
BASE
19/32" X 5-1/2"



WP225

BASE
19/32" X 5-1/2"



WP125


CASING
13/16" X 3-1/2"

PROFILES ARE NOT NECESSARILY ACTUAL SIZE




WPC346

CASING
5/8" X 2-1/4"



WPC347

CASING
9/16" X 3-1/2"



WPB618

BASE
9/16" X 5-1/4"



WPB633

BASE
1/2" X 3-1/4"

MOULDING

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES



FJ

WP111

CASING
1-1/8" X 3-1/2"



FJ
WP

WP112

CASING
11/16" X 3-1/2"



WP211*

BASE
1-1/16" X 4-1/2"



FJ
FX

WP121

CASING
5/8" X 2-1/2"



FJ

WP212

BASE
9/16" X 4-1/2"



FJ
FX

WP213

BASE
9/16" X 5-1/8"



FJ

WPC295

BASE

11/16" X 3-1/2"


WP
FJ

WPB695

BASE

9/16" X 6-1/2"



FJ

WPB395

BASE

9/16" X 4-1/2"

MOULDING

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



MDF

WPB2184

BASE
9/16" X 4"



MDF
FX

WPB218514

BASE
9/16" X 5-1/4"



MDF

WP432

BASE
9/16" X 3-1/4"



PFJ

WP297

BASE
9/16" X 7"



PFJ

WP295

BASE
9/16" X 5-1/4"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



FJ

WP209

BASE
1/2" X 5-1/4"



FJ

WP208

BASE
9/16" X 3-1/4"



FJ
FX
PMDf

WPB514

BASE
1/2" X 5-3/16"



FJ
FX
PMDf

WPB314

BASE
1/2" X 3-3/16"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



C322

CASING
5/8" X 2-1/2"



C522

CASING
5/8" X 3-1/2"



B322

CASING
9/16" X 3-1/2"



B522

CASING
9/16" X 3-1/2"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions


**WP108**

CASING
9/16" X 2-1/2"

FJ

**C218**

CASING
5/8" X 2-1/8"

FX
FJ**WP113**

CASING
9/16" X 3-1/2"

FJ
FX

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP110*

CASING
9/16" X 3-3/8"




WPFP*

FLUTED PILASTER
11/16" X 5-1/2"



BASEBLOCK*

1-1/8" X 6-1/2"



BULLSEYE ROSETTE



3-1/2" X 3-1/2"

5-1/2" X 5-1/2"


Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



FJ

WP355CROWN
9/16" X 5-1/2"FJ
FX
PMDf**WP313**CROWN
9/16" X 4-1/4"WP
FJ**WP312**CROWN
9/16" X 3-5/8"

WP


WP352CROWN
9/16" X 2-3/4"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP322

CROWN
9/16" X 4-1/2"




WP373*

PICTURE MOULD
11/16" X 1-3/4"




WP374*

BED MOULD
9/16" X 1-3/4"



Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP351

CROWN
1-7/16" X 5-1/4"


H=3-15/32"
P=3-7/8"



WP351C*

CRADLE
1-7/16" X 2-1/2"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions




WP398*

CROWN

1-5/16" X 7-1/4"

P=5-1/16"

H=5-3/16"




WP396

CROWN

1-1/8" X 5-1/2"

P=3-13/16"

H=3-3/16"



*SPECIAL ORDER



PROFILES ARE NOT NECESSARILY ACTUAL SIZE

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions




WP310

CROWN
1" X 7"





WP309

CROWN
1 1/16" X 5-1/4"



Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP300

COVE
11/16" X 11/16"
WP



WP705

PANEL MOULD
3/4" X 1-1/8"
WP



WP701*

PANEL MOULD
3/4" X 1-1/4"



WP788*

DOOR MOULD
11/16" X 1-1/2"
WP



WP706

PANEL MOULD
3/4" X 2"
WP



WP711*

DOOR MOULD
5/16" X 3/4"
WP



WP703

DOOR MOULD
7/16" X 11/16"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP902

BACKBAND
11/16" X 1-1/8"



BYP*

BEADED CEILING
5/8" X 3-1/2"



1X8

NICKEL GAP



122YP*

1" X 6"
T&G

*SPECIAL ORDER
PROFILES ARE NOT NECESSARILY ACTUAL SIZE

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP404

OUTSIDE CORNER
1-1/8" X 1-1/8"
WP



WP403

OUTSIDE CORNER
3/4" X 3/4"
WP



WP451

SHOE MOULD
7/16" X 3/4"
FX • PFJ • WP



WP324

QUARTER ROUND
3/4" X 3/4"



WP433

FULL ROUND
1-3/16" X 1-3/16"



WP254

1/2" X 3/4"



WP316

HALF ROUND
11/16" X 1-1/2"



WP342

SCREEN MOULD
1/4" X 3/4"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP1006*

CHAIR RAIL
1-1/4" X 3-1/2"



WP1001*

MANTEL MOULD
1-1/2" X 4-5/8"



WP1007

CHAIR RAIL
1-1/8" X 2-1/2"

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions



WP9248
11/16" X 1-3/4"

FJ
WP




WP876
7/16" X 1-3/8"



WP

WB268
1/4" X 1-1/8"



WP180
BRICK MOULD
1-1/4" X 2"




WP514
WINDOW STOOL
1/4" X 5-1/4"



WP614*
WINDOW STOOL
11/16" X 6-1/4"



WP714
WINDOW STOOL
11/16" X 7-1/4"



STOCKED IN:
 PRIMED FINGER JOINT
 MDF
 WHITE PINE
 POPLAR
 RED OAK

MOULDING

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES

SC HDBD

HARDBOARD
FLUSH
6/8 • 8/0

ROMAN

SMOOTH
PASSAGE/BIFOLD
6/8 • 8/0

2 PANEL SQUARE

SMOOTH
PASSAGE/BIFOLD
6/8 • 8/0

CHEYENNE

SMOOTH
PASSAGE/BIFOLD
6/8 • 8/0

RIVERSIDE

RAISED PANEL
SMOOTH
PASSAGE/BIFOLD
6/8 • 8/0

COLONIST*

SMOOTH
TEXTURED
PASSAGE/BIFOLD
6/8 • 8/0

MOULDING


FLAT STOCK

INTERIOR DOORS

STAIR PARTS


TECHNICAL INFORMATION

NOTES




LINCOLN PARK*

FLAT PANEL
SMOOTH
PASSAGE/BIFOLD
6/8 • 8/0



WINSLOW*

FLAT PANEL
SMOOTH
PASSAGE/BIFOLD
6/8 ONLY





LIVINGSTON*

3 PANEL
SMOOTH
PASSAGE/BIFOLD
6/8 • 8/0


HAMEL*

SMOOTH
PASSAGE/BIFOLD
FLUSH W/KERF LINES
6/8 • 7/0



LOGAN*

FLAT PANEL
SMOOTH
PASSAGE/BIFOLD
6/8 • 8/0



BERKLEY*

SMOOTH
PASSAGE/BIFOLD
FLUSH W/KERF LINES
6/8 • 7/0

SHAKER/SQUARE STICKING • FLAT PANEL

1-3/8" • STILE & RAIL • 6/8 & 8/0
(1-3/4" AVAILABLE IN 2/8 AND 3/0 WIDTHS)

MOULDING

FLAT STOCK


INTERIOR DOORS

STAIR PARTS


TECHNICAL INFORMATION

NOTES


730*
PRIMED
MDF




720*
PRIMED
MDF




755*
PRIMED
MDF



782*
PRIMED
MDF




760*
PRIMED
MDF



OAK NEWELS & TREADS

ALL RED OAK



MOULDING


FLAT STOCK

INTERIOR DOORS

STAIR PARTS


TECHNICAL INFORMATION

NOTES




8070

PLAIN TREAD
1" X 11-1/2" x 48"
RED OAK



8070MR

OAK TREAD
1" X 11-1/2" x 48"




8071*

(SPECIFY LH or RH)
FALSE END CAP



8076*

FALSE RISER



8072*

FALSE END CAP

*SPECIAL ORDER

HANDRAILS & BALUSTERS

- MOULDING
- FLAT STOCK
- INTERIOR DOORS
- STAIR PARTS
- TECHNICAL INFORMATION
- NOTES

6040

1-3/4"



OAK

7/8"

6210

2-5/8"



OAK

1-7/8"

2-3/8"

6010

2-1/4"



OAK

1-1/2"

2-3/8"

6002

1-5/8"



OAK

2-3/4"

Handrails can be plowed upon request

PLA44H

ITW44H

2TW44H

1BASK44H

2BASK44H

SATIN BLACK 1/2" HOLLOW IRON BALUSTERS

44"

44"

44"

44"

44"

42"

5060

PRIMED

1-1/4" X 42"

PSH02A

PITCH SHOE



AK01A

ADJUSTABLE KNUCKLE



M06A

FLAT SHOE



STAIR HARDWARE



3001

RAIL BOLT



3000

1" OAK PLUG



3002

STANDARD DUTY
HANDRAIL BRACKET

CHROME
BLACK
SATIN NICKEL
DARK BRONZE



S3008

SURE-TITE
NEWEL FASTENER



7033

ROSETTE
4-5/16" X 6"
Red Oak



7037

OVAL ROSETTE
4" X 5-1/2"
Red Oak

Moulding dimensions subject to change without notice, contact your local WestPac office for correct dimensions

MOULDING

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES

STAINING INSTRUCTIONS

RECOMMENDED WOOD STAINING PROCEDURE

WOOD PREPARATION

Wood must be dry and cleaned of dirt, grease, wax, polish, and marks. See STEP 1 for details.

(For exterior wood doors, Western Pacific recommends Epifanes Wood Finish Matte top coat for the best results and long lasting finish. (Available at Marine Supply. Epifanes.com))

THE "FINGERNAIL TEST"

Determine if you have a soft wood or a hard wood.

We consider Fir, Hemlock and Alder to be softwoods and Oak, Cherry and Maple are typically hardwoods. If your fingernail dents the surface when you scratch it, you have a soft wood.

Since soft woods tend to absorb stain unevenly and become blotchy easily, pre-treat the wood using pre-stain wood conditioner before staining. This critical extra step will help you control stain color penetration and prevent blotchiness.

CHOOSING A COLOR

Your finished color is determined by many factors, from the color of the stain selected to how long the stain is left on.

But remember: Different species of wood absorb stain differently. Test the color on an inconspicuous area or sample board before you start staining the most visible parts of your project.

Always stop your staining process if you are not achieving your desired finish and ask a painting professional for additional advice.

To assure the highest quality results when applying interior wood stain, follow these steps:

STEP 1: Start with a medium grade of sandpaper (e.g., 120-grit) and gradually work your way to a finer grade (e.g., 220-grit).

Sand in the direction of the grain for a smooth uniform finish, and remove all sanding dust (using a vacuum, dry paint brush or tack cloth) before finishing.

STEP 2: Mix the stain thoroughly before you begin and frequently while you're staining. This helps keep the color consistent throughout the project. Ingredients in stains and finishes can settle over time. Stir until all settlement is evenly dispersed. Shaking will only add unwanted bubbles to the product.

STEP 3: Before proceeding, apply the stain on a discreet area of wood to test the color.

TIP: ● ● ● ●

Apply stain only at the proper temperature. For most stains, 70°F is the optimum, with the safety range from 50° to 90°F.

Stains do vary, so check the label first. Avoid high humidity when applying stain. All finishes, including stains and paint, have trouble drying in moist conditions.

STEP 4: Apply stain by brushing or wiping it in the direction of the grain, using smooth, even strokes. Wipe off any excess.

TIP: ● ● ● ●

Avoid unattractive lap marks by applying stain from an unpainted area back into the last wet stain. In other words, don't let a section of stain dry before you blend it in with stain from an adjoining section.

STEP 5: Let dry completely (usually 24 hours).

Apply a second coat of stain if you want a darker look.

STEP 6: After the wood is dry, brush or spray on a uniform coat of your top coat product. After the top coat dries, lightly sand the trim using 220-grit sandpaper to eliminate brush strokes or paint drips. Use a damp sponge or tack cloth to remove all sanding dust. Recoat your top coat and follow the sanding procedure until your desired finish is achieved.

MOULDING

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES

FINISH LUMBER DESCRIPTIONS

3/4" thick with four square edges, and available in random lengths.

Custom Milling Available in all species:

- Sanding
- Ripping to Custom Width
- Planing to Custom Thickness

RED OAK

Sapwood is white to light brown and the heartwood is a pink or reddish brown. Similar in appearance to White Oak, but with smaller grain rays. Red Oak is mostly straight-grained, with a coarse texture.

WHITE OAK

The sapwood is light-colored and the heartwood is light to dark brown. White Oak is mostly straight-grained with a medium to coarse texture, and with longer grain rays than red oak.

EASTERN HARD MAPLE

Creamy white in color with a fine, uniform texture and generally mixed grain.

AMERICAN CHERRY

Rich red to reddish brown. Will darken with age and on exposure to light. May contain some creamy white sapwood. Fine uniform, straight grain, satiny, smooth texture.

CLEAR ALDER

Light brown with a yellow or reddish tinge. Fairly straight-grained with a uniform texture. Occasional pin knots may be present.

KNOTTY ALDER

Light brown with a yellow or reddish tinge. Fairly straight-grained with a uniform texture. Multiple large open and tight knots will be present.

PRIMED FJ PINE

Factory primed for superior paint finish applications.

EASTERN POPLAR

Solid paint grade hardwood. Smooth and even surface that paints out beautifully. Our high quality Eastern Poplar is lighter in color, more dense, and less fuzzy when machining than Western varieties.

CLEAR RADIATA PINE

Radiata Pine is plantation grown, has wide growth rings and is mostly knot free. Its neutral yellowish color is great for staining.

MOULDING

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES

PAINTING INSTRUCTIONS

RECOMMENDED PROCEDURE TO PAINT WOOD AND MDF MOULDINGS AND BOARDS

MOULDING

PART 1 • PREPARE THE TRIM

STEP 1: Use a damp sponge to clean dirt and grime from trim. If needed, use the rough side of a sponge to ensure a clean starting surface.

STEP 2: Sand the surface. After the trim has been sanded, use a damp sponge to wipe away any dust.

SANDING TIP: If the trim is smooth, lightly sand using 120-grit sandpaper until all shine disappears from the trim.

If the trim has a rough milling area start by sanding with coarse, 80-grit sandpaper. Then, move to less-coarse sandpaper such as 100 or 120-grit to smooth the surface.

STEP 3: Fill in holes, dents and cracks with a lightweight spackling compound. (Follow directions on the spackling container for best results.) When the spackle dries completely, lightly sand the spackled areas using 120-grit sandpaper to smooth out the surface. Use tack cloth to remove any sanding dust from the trim.

STEP 4: Dust off walls and ceiling around the trim to ensure painter's tape adheres well. Apply painter's tape to walls and ceilings surrounding the trim, being careful not to stick the tape to the trim itself. To prevent paint from bleeding through the tape, try to use one long piece of tape instead of multiple shorter pieces.

STEP 5: After you have applied the tape, press the tape's edges with a clean spackling or putty knife to ensure adhesion, as this helps prevent the paint from bleeding through the edges.

FLAT STOCK

INTERIOR DOORS

STAIR PARTS

TECHNICAL INFORMATION

NOTES

PART 2 • PAINT THE TRIM AND BOARDS

STEP 1: Apply primer to trim, covering any bare wood and spackled areas. Allow primer to dry for 24 hours. After the drying period, if bare wood or spackle is showing, apply another coat of primer to the trim.

STEP 2: After the primer dries, lightly sand the trim using 120-grit sandpaper to eliminate brush strokes or paint drips. Use a damp sponge or tack cloth to remove all sanding dust.

STEP 3: Apply paint to the trim using short, horizontal brush or spray-gun strokes. Repeat the motion until a few feet of trim (not the full length) are covered in paint.

STEP 4: Allow the paint to dry for 24 hours. After the drying period, for latex paint lightly sand the trim using 180-grit sandpaper to eliminate brush strokes or paint drips. Use a sponge or tack cloth to remove all sanding dust. Oil based paint does not require sanding between paint applications. Apply paint to the trim using short, horizontal brush or spray-gun strokes. Repeat the motion until a few feet of trim (not the full length) are covered in paint.

STEP 5: Before paint dries, carefully pull tape off of the wall and trim.

RETURNS

Material returns are subject to Western Pacific approval. Western Pacific will accept a return of a product, for credit, that has been purchased from Western Pacific inventory. Western Pacific will not accept a return of product, for credit, that has been modified or damaged by a person or party other than Western Pacific. Examples of such product are millwork items that have been cut in length, hardware not in its original box, etc. Furthermore, product ordered for a specific job, such as pre-hung doors, non-stock doors only, pre-finished millwork, etc., may not be returned for credit.

CANCELLATIONS & CHANGES

Once an order has been placed for custom items, pre-hung doors, or windows, the order may not be cancelled or otherwise changed.

WARRANTY

Western Pacific makes no representations or warranties, either expressed or implied, with respect to the building materials beyond those specifically made by the manufacturer. We can help coordinate warranty resolution for products, but it will be your responsibility to contact the manufacturer directly. Western Pacific is not responsible for any type of freight charges for warranty issues and is not responsible for warranty issues or discrepancies for products exported outside the USA.

DELIVERY

Western Pacific will make every effort to deliver all product in a timely manner. However, Western Pacific assumes no liability for theft, or delivery delays, beyond the reasonable control of Western Pacific.

PAYMENT

All charges are due and payable on the 10th of each month, except for cash accounts which are due prior to production. Any billing discrepancies must be raised within 10 days. Buyer acknowledges that any quotes or bids from Western Pacific are only for the materials listed and buyer assumes responsibility to ensure quantities are sufficient to complete the job.



March • 2021

LOCATIONS

Austin • Texas

15855 Long Vista Dr. • Ste 103

Austin, TX 78728

Phone: 512-989-1445

Houston • Texas

7607 Bluff Point Drive

Houston, TX 77086

Phone: 832-975-0070

Fax: 832-975-0071

Denver • Colorado

320 S Lipan Street

Denver, CO 80223

Phone: 303-454-8811

Fax: 303-394-3312

Seattle • Washington

1101 Industry Street

Everett, WA 98203

Phone: 425-366-8828

Fax: 425-742-5280

Bellevue • Washington Design Studio

13208 NE 20th Street • Suite 150

Bellevue, WA 98005

Phone: 425-250-8327

Fax: 425-558-5828

Portland • Oregon

2805 NW 31st Avenue

Portland, Oregon 97210

Phone: 503-223-8818

Fax: 503-224-9129

Medford • Oregon

502 Parsons Drive

Medford, OR 97501

Phone: 541-772-8818

Fax: 541-770-3736

HOURS

MONDAY - FRIDAY

7 AM - 4:00 PM

gowestpac.com